

Recommended Adhesive List

****ALL StareCasing products must be installed using a POLYURETHANE-based construction adhesive, per StareCasing Installation Instructions specifications****

- 1. Franklin Titebond-** Premium Polyurethane Construction Adhesive
- 2. Loctite PL Premium-** Polyurethane Construction Adhesive
- 3. Mapei Ultrabond 905-** Professional Urethane Construction Adhesive
- 4. Quikrete 990210-** Polyurethane Construction Adhesive
- 5. SikaBond Construction Adhesive**

All listed adhesives are low VOC and virtually odorless. They are available in a 10 oz. caulk tube for ease of use. One 10 oz. tube of adhesive is enough to install about two 36" steps, treads and risers. Please follow the StareCasing Installation instructions for application details and specifications.

****PLEASE NOTE - PRODUCTS INSTALLED WITH ANY ADHESIVE OTHER THAN POLYURETHANE-BASED CONSTRUCTION ADHESIVE, PER THE STARECASING INSTRUCTIONS, WILL NOT BE COVERED BY STARECASING AND AUTOMATICALLY VOIDS THE WARRANTY.**